

Вентилятор

AIRPACK

Технические характеристики

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04

Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93



AIRPACK

High pressure blower (side channel compressor). High pressure and surprisingly high air-flow.

- High pressure
- Sound-suppressed
- Continuous operation
- Can be fitted in every position
- Air-inlet and outlet adapter can be mounted on both sides of the turbine



SPECIFICATIONS

AIRPACK 3x400 V

Voltage	V~	3 x 400
Power consumption	W	2200
Frequency	Hz	50 / 60
Air flow (20°C)	l/min	3900
Pressure static	Pa	30 000
Ambient temperature	°C	
Noise emission level LpA	dB	73
Protection type (IEC 60529)		IP 54
Intake opening (outside)	mm	Ø 60
Outlet opening (outside)	mm	Ø 60
Weight	kg	26.0
Size (L x W x H)	mm	373 x 327 x 365
Marking of conformity		
Approval mark		
Protection class I		

AIRPACK 3x230 V

Voltage	V~	3 x 230
---------	----	---------




Process Heat > Blowers > AIRPACK

Power consumption	W	2200
Frequency	Hz	50 / 60
Air flow (20°C)	l/min	3900
Pressure static	Pa	30 000
Ambient temperature	°C	
Noise emission level LpA	dB	73
Protection type (IEC 60529)		IP 54
Intake opening (outside)	mm	Ø 60
Outlet opening (outside)	mm	Ø 60
Weight	kg	26.0
Size (L x W x H)	mm	373 x 327 x 365
Marking of conformity		
Approval mark		
Protection class I		

Process Heat > Blowers > AIRPACK

ACCESSORIES



Air hose $\varnothing$ 60 mm for SILENCE, AIRPACK

107.288 - PVC air hose $\varnothing$ 60 mm for connection between blower and heater




Hose clip, $\varnothing$ 38 mm and
 $\varnothing$ 60 mm

107.287 - Hose clip for $\varnothing$ 38 mm and
 $\varnothing$ 60 mm air hose




Hose connection adaptor for SILENCE, AIRPACK

107.291 - Hose connection adaptor with
1 air outlet for $\varnothing$ 38 mm hose.
Push-fit on air outlet



Hose connection adaptor for SILENCE, AIRPACK

107.278 - Hose connection adaptor with
2 air outlet for $\varnothing$ 60 mm hose.
Push-fit on air outlet



Hose connection adaptor for SILENCE, AIRPACK

107.292 - Hose connection adaptor with
2 air outlets for $\varnothing$ 38 mm hose.
Push-fit on air outlet



Closing cap for ROBUST, AIRPACK

107.241 - Closing cap $\varnothing$ 38 mm push-fit
on hose connection adaptors 107.292
and 107.293



Closing cap for SILENCE, AIRPACK

107.240 - Closing cap $\varnothing$ 60 mm attachable to
hose connection adaptor 107.238
and 107.278

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04

Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: ets@nt-rt.ru || www.leister.nt-rt.ru